

Unique Effects Jacinthe

Installation & Care Instructions

- Handling:** Store the material in a clean and dry place (65 – 90 degrees). Proper ventilation in the storage area is recommended. Do not dispose of any moisture absorbent packets from within the rolls until the date of installation. Prolonged storage of this natural product is not recommended.
- Surface Preparation:** Ensure surfaces are dust free, smooth, dry, firm and uniformly colored and primed. Do not install over non-porous surfaces. Previously painted walls may be wiped down with Tri Sodium Phosphate to remove any grease or oil. Glossy paint should be dulled by sanding. Never install these materials over new plaster or un-primed walls. It is best to remove all dust and prime all surfaces with an appropriate high quality acrylic wallcovering primer. All surfaces to be installed should be tested by the installer to determine suitable adherence of existing coatings prior to installation.
- Trimming:** Before cutting and hanging, check: color, condition, quantity, and quality. Be certain pattern and color are as ordered. Be sure that there is sufficient material to complete the job. No allowances will be given for any material once cut on your site. Should you have any questions, contact your MDC representative or customer care at (800)621-4006 before proceeding. Even though great care has been taken in the production of this wallcovering, natural variations in color can occur. Table trim the long edges of this material using a new sharp blade for each cut. This will help insure a clean finished edge.
- Application:**
1. The wall should be properly primed with Roman R35 or Roman PRO-977. You must use an extra strength grade of heavy-duty premixed clear adhesive (i.e. Roman Pro 880 or 838). Do not dilute. Using another type of adhesive will be solely at the risk of the installer.
 2. Apply material in consecutive bolt sequence (if so numbered.) Cuts should be made with a sharp razor blade. Do not attempt more than one cut per blade.
 3. You will have two applications of adhesive. First, apply an even and medium coat of adhesive to the wall. Make sure the adhesive is spread out evenly over the surface to ensure good adhesion each time you roll the adhesive. Allow the adhesive to set for 30 minutes before applying wallcovering. Then, roller apply a medium to light layer of adhesive to the back of the material and allow to stand/book for 15 minutes prior to wall application. Never allow the adhesive to get on the face of the material. This is a textured and natural wallcovering. Therefore, removal of adhesive will require great care and is therefore best if you prevent it by being careful.
 4. Use strips in exact order as they are cut from the roll. Straight hang – do not reverse strips. Hang only 1-2 strips at a time, carefully smoothing the material with a bristle sweep or a plastic / Plexiglas smoothing tool to eliminate air bubbles and ensure full adhesion. Take care to not abrade on corners.
 5. Immediately wipe off excess adhesive on all edges of the wallcovering by using nearly dry sponge or clean cloth. Use a single wiping motion and attempt to blot from face. Make sure that the thread direction must be followed to avoid thread destruction.
 6. STOP AFTER APPLYING 3 STRIPS. If there are any excessive variations in color and/or color match, this should be immediately communicated to MDC for inspection before proceeding further with installation. This product is designed to have a paneled effect between sheets; this is normal and to be expected. MDC assumes no responsibility for the installation of material beyond three panels. Under no circumstances will MDC be responsible for labor. This is a common industry standard.
- Special Note:** Unique Effects Jacinthe wallcoverings are manufactured to the highest quality standards possible. However, it should be noted that some items by their nature, require care in handling and installing so as to provide an acceptable wall finish. ***This product should not be used in areas with a high moisture content or prolonged direct exposure to sunlight.***
- Maintenance:** Use only a clean dry white cloth with a single wiping motion to maintain cleanliness of the Jacinthe wallcovering. Do not use wet cloth or any cleaning agent as this will react with the product and may affect the color and appearance. As this wallcovering is made of natural material, slight discoloration may occur due to aging or when placed with excessive UV exposure.

For additional information or technical support contact MDC Customer Care at 800-621-4006



MDC