

# Dimension Walls

## Installation Instructions

- Inspection:** Final inspection should be made by the installer on site as to correct pattern, color, and any defects in craftsmanship.
- No claims, including labor, will be accepted beyond the installation of 2 panels. Application of material is interpreted as acceptance of material and conditions of installation. Small differences in shading between different run lots or subtle differences between sample and actual delivered material cannot be avoided. Should you have any questions, contact your MDC representative or customer service (800)621-4006 before proceeding.
- No returns will be accepted after the material has been cut.
- Surface Preparation:** Ensure surfaces are dust free, smooth, dry, firm and uniformly colored. Do not install over non-porous surfaces. Previously painted walls may be wiped down with Tri Sodium Phosphate to remove any grease or oil. Glossy paint should be dulled by sanding. Never install these materials over new plaster or un-primed walls. It is best to prime all surfaces with an appropriate high quality acrylic wallcovering primer. All surfaces to be installed should be tested by the installer to determine suitable adherence of existing coatings.
- Panel Preparation:** Dimension Wall panels may be shipped via one of two methods. Sheets that are shipped rolled in boxes require time to relax before installation. Any rolled panels should be laid flat for at least 24 hours under typical site conditions. Larger orders shipping flat via crate do not require any relaxing time.
- Trimming:** Dimension Walls panels are sold by the 4' x 8' sheet. Required cuts should be made on the table using a sharp utility knife. Take care to trim accurately. Be sure edges are even before installation. The product ships with a clear protective film that should be removed prior to leaving the jobsite.
- Application:**
1. The wall should be properly primed with Roman R35. The installer must use Durabond D-745 Fire Retardant Water-Based wall adhesive ONLY. Do not dilute. Using another type of adhesive will not result in an acceptable installation.
  2. Apply an even coat of adhesive to the wall using a Wooster Textured Paint roller. Make sure the adhesive is spread out evenly over the entire surface to ensure good adhesion. The coverage rate is approximately 50 square feet per gallon. Apply additional adhesive near the edge of the area as well as the ½" lip. This procedure will help avoid open seams. The adhesive is fast grabbing - allow it to tack up briefly prior to applying the sheet to the wall. Never allow the adhesive to get on the front of the material.
  3. Two people are required to lift sheet and apply it to the wall. Hang only 1 panel at a time, carefully matching the design at the sides. Two sides of each panel have a ½" lip for overlapping consecutive sheets. Smooth material with a short nylon smoothing brush to eliminate air bubbles and ensure adhesion.
  4. STOP AFTER APPLYING 2 PANELS. If there are any excessive variations in color and/or color match, this should be immediately communicated to MDC Wallcoverings for inspection before proceeding further with installation.

**MDC assumes no responsibility for the installation of material beyond two panels. Under no circumstances will MDC be responsible for labor. This is an industry standard.**