

Legends Mondiale

Superlative Wallcoverings

Installation Instructions

Inspection:

Be sure all material has the same run number before installation. Final inspection should be made as to correct pattern, color, and any defects in craftsmanship. No claims, including labor, will be accepted beyond the installation of 3 strips. Application of material is interpreted as acceptance of material and conditions of installation. Small differences in shading between different run lots or subtle differences between sample and actual delivered material cannot be avoided. Should you have any questions, contact your MDC representative or customer service (800)621-4006 before proceeding.

Surface Preparation:

Ensure surfaces are dry, firm, and uniformly colored. Do not hang over glossy or non-porous areas. Painted walls should be wiped down with Tri Sodium Phosphate to remove grease or soil. Glossy paint should be dulled by sandpaper. Never hang over new plaster or un-primed wall areas. For wallboard or drywall, fill all cracks and prepare the surface with an acrylic basecoat.

Application:

1. Apply a pre-mixed, heavy-duty vinyl adhesive to the wall. Make sure the adhesive is spread out evenly over the whole surface to insure good adhesion to the wall. This will avoid open seam. Do not dilute the adhesive. Never allow the adhesive to get on the front of the material.
2. Use strips in exact order as they are cut from the roll. Reversing strips may reduce shading at the seams. Hang only 1-2 strips at a time.
3. Cut material in consecutive bolt sequence, as marked on the end of each wrapper. Pre-trim edges with a straight edge on a cutting table. Use a very sharp cutter with large blade. Replace blade after each cut.
4. Use strips in exact order as they are cut from the roll. Reversing strips may reduce shading at the seams. Fill in over doors and windows as they come with strips cut in consecutive order from the roll. Hang only 1-2 strips at a time. For corners and joints, especially for the darker colors, the manufacturer advises painting the wall on places where there will be joints in the same color as the color of the wallcovering.
5. Smooth material to hanging surface with a soft bristle to eliminate air bubbles and ensure adhesion.
6. STOP AFTER APPLYING 3 STRIPS. If there are any variations in color and/or color match, this should be immediately communicated to MDC Wallcoverings for inspection before proceeding further with installation. Natural wallcoverings will tend to lightly panel on occasion.

MDC assumes no responsibility for the installation of material beyond three panels. Under no circumstances will MDC be responsible for labor. This is an industry standard.

Cleaning:

Pierre - Remove stains immediately with a clean sponge or tissue. Rinse with clear water if necessary. Use a soft detergent [like dishwashing detergent] if necessary and rinse with clear water. Dry with a clean tissue. Avoid hard rubbing and the use of too much water. Excessive water or soaking will damage the wallcovering.
Tissat - Vacuum Only.

Special Note:

Mondiale wallcoverings have been manufactured to the highest quality standards possible. However, it should be noted that some items by their nature, require care in handling and installing so as to provide an acceptable wall finish.

The above is intended only as a guideline; the installer has final responsibility for proper installation.

MDC Wallcoverings

1200 Arthur Avenue
Elk Grove, Illinois 60007
tel 847.437.4000
fax 847.437.4017

www.mdcwallcoverings.com