



Installation Instructions for FUZE Over Dry---Erase Marker Board

1. **Tape off the frame and all other areas not intended to be painted with low adhesion masking tape.**
2. **Scuff marker board surface.**
 - ✓✓ Use medium grit sandpaper (100 ---120 grit)
3. **Dry Wipe surface with a clean cloth to remove dust from sanding.**
4. **Prime surface with *Glidden Gripper, Kilz Premium, or Sherwin---Williams Multi---Purpose Primer.***
 - ✓✓ Use 3/16" nap roller
 - ✓✓ It is important to "over---roll" the primer application to insure that it achieves a full bond everywhere; apply the primer generously, level it out, back roll, and then rebalance for complete coverage
 - ✓✓ Allow primer to dry for a minimum of 90 --- 120 minutes, 4 hours preferred.
5. **Sand smooth (lightly) the primed surface.**
 - ✓✓ Use fine grit sandpaper (180 grit)
6. **Dry Wipe surface with a clean cloth to remove dust from sanding.**
7. **Apply FUZE according to installation instructions included in each kit.**