



Installation Instructions for FUZE Over Glass

1. **Clean surface thoroughly with acetone.**
 - ✓✓ Allow to dry

2. **Prime surface with *Zinsser Bullseye 123*.**
 - ✓✓ Use 3/16" nap roller
 - ✓✓ It is important to "over---roll" the primer application to insure that it achieves a full bond everywhere; apply the primer generously, level it out, back roll, and then rebalance for complete coverage
 - ✓✓ Spray application of primer is recommended
 - ✓✓ Allow primer to dry for a minimum of 4 hours

3. **Sand smooth (lightly) the primed surface.**
 - ✓✓ Use fine grit sandpaper (180 grit)

4. **Dry Wipe surface with a clean cloth to remove dust from sanding.**

5. **Apply FUZE according to installation instructions included in each kit.**