



Installation Instructions for FUZE Over Galvanized and Ungalvanized Steel

- 1. Clean surface thoroughly with acetone.**
 - Remove all oil and grease residue
 - Allow to dry
- 2. Dry Wipe surface with a clean cloth to remove dust.**
- 3. Spray application of FUZE is recommended. If applying FUZE White, evaluate the initial application for adequate coverage and reapply after 24 hours of dry time if deemed necessary to achieve the uniform coverage you desire.**
- 4. Note: Stainless steel application is not recommended.**

Version 8+1+14