

FUZE

DRY ERASE PAINT

Installation Instructions for FUZE Over Wallcovering (ie: Walltalkers™)

- 1. Scuff wallcovering surface.**
 - // Use medium grit sandpaper (100 —120 grit)
- 2. Dry Wipe surface with a clean cloth to remove dust from sanding.**
- 3. Prime surface with *Sherwin Williams Adhesion Primer*.**
 - // Use 3/16" nap roller
 - // It is important to "over—roll" the primer application to insure that it achieves a full bond everywhere; apply the primer generously, level it out, back roll, and then rebalance for complete coverage
 - // Allow primer to dry for a minimum of 90 – 120 minutes, 4 hours preferred
- 4. Sand smooth (lightly) the primed surface.**
 - // Use fine grit sandpaper (180 grit)
- 5. Dry Wipe surface with a clean cloth to remove dust from sanding.**
- 6. Apply FUZE according to installation instructions included in each kit.**